

# INSTALL GUIDE

## SEQUENTIAL HIGH MOUNTED STOP LIGHT

### DODGE CHARGER 1<sup>st</sup> & 2<sup>nd</sup> GEN

1. Remove HIGH MOUNTED STOP LIGHT from your car

2. ONLY 2<sup>nd</sup> GEN:

Remove push-button for trunk and backup camera (if equipped)



3. 1<sup>st</sup> Gen: Remove the red plastic from the (left) black base

2<sup>nd</sup> Gen: Use a flathead screwdriver and start (right) to pry open the stop light



3. Use a side/wire cutter to cut and remove the plastic welded anchors.

1<sup>st</sup> Gen: 6 times (left pic)

2<sup>nd</sup> Gen: 4 times (right pic)



4. Remove the factory PCB and put in the new PCB

5. Use some adhesive to fix the new PCB in the housing. 4 Small dots recommend where the original PCB was mounted

6. Last step

1<sup>st</sup> Gen: Put the 2 pieces back together

2<sup>nd</sup> Gen: Glue the 2 pieces back together (shrink foil might be useful)